

"T"-Zyme

TriPlex
TECHNICAL SERVICES, LTD.

Trap & Drain
Deodorizer

Tomorrow's Technology
Today™



Bacteria/Enzyme Culture + Deodorant

Digests Organic Wastes, Reduces Volume of Solids, Kills Odors. Each milliliter of "T"-Zyme contains a minimum of 17.5 million aerobic and facultative anaerobic high enzyme producing bacteria which will multiply greatly when used as directed to digest wastes. Bacteria are several strains of nonpathogenics including Bacilli sp. Contains no acids or corrosives, and is entirely nonpolluting. Has a long shelf life when stored as directed.

Typical Properties

pH	8.5 -9.5
Water Solubility	99%
Boiling Point	100 degrees Centigrade
Appearance	Green/Blue Solution
Odor	Spearmint

Directions:

Directions for Drain & Grease Trap Cleaning

GREASE TRAPS (RESTAURANTS, INSTITUTION KITCHENS)

Pump out trap, then add 1 qt. per 24 cu. Ft. capacity (946 ml per 0.68 meters cubed). One week later, begin preventative maintenance schedule: At close of business day, flush lukewarm water down each drain leading to trap for 5 seconds to clear line of harsh chemicals which can reduce bacterial activity. Dilute ½ pint (230 ml) with 1 qt. (946 ml) of lukewarm water and pour approximately half of the solution down each drain. Let mixture remain in drains overnight. Next morning flush lukewarm water down drains for 5 seconds. For 24 hour business operations, use same procedure, but begin treatment at time of lowest water flow down the drains.

DRAIN LINES, FEEDER LINES (BUILDINGS AND APARTMENTS)

Add 8 oz. (230 ml) directly to any sump or drain pipe and 2 oz. (60 ml) twice a week thereafter. To treat lines and pipes, begin on first floor and proceed upwards as the condition is brought under control. Continue treatment on lower floors as you continue upward. Pour 2 oz. (60 ml) down every drain at bedtime twice weekly. If line is dry, follow with a cup of lukewarm water.

CEMENT VAULT TOILETS (PARKS, ROADSIDE REST STOPS)

Add 1 gallon (3.8 liters) directly. If necessary, add water to cover the solids. Use 1 pint (480 ml) each week for continued waste digestion.

DIRECTIONS FOR USE AS A URINE ERADICATOR

Simply insert a trigger sprayer into the bottle and you have a ready-to-use product which will eliminate the odors produced from the organic material and decomposed salts associated with urine. The area should first be cleaned of excess material. If the area is not moist, use lukewarm water on the area to be treated with product.

Tri-Plex Technical Services, LTD. P.O. Box 36 Freeburg, IL 62243
1-877-361-8787 or 618-539-5843 Fax:1-618-539-6245